



Installation Guide (For CMS-L3030 to CMS-L4343)

LS/ESC

Warning

Caution with main supply and live wires. Install with qualified technician or trained personnel.


Universal Bracket can be used for any type of installation as shown below.



Important Notes:


All screens are thoroughly inspected and fully tested operational in factory. We accept no liability whatsoever for any losses due to improper wiring, installation, operation, or any unauthorized alternation at the point of installation. All trademarks contained in this installation guide are the property of their respective owners.

STEP 1



A) Mark the bracket position with the help of universal bracket.


STEP 2



B) Drill Dia 10mm Holes to a depth 35mm.
(Note: Do not drill too deep)


C) Insert M8 Anchor into the hole.
D) Use pin punch to expand the anchor.

STEP 3



E) Terminate 4-cores cable as shown

STEP 4



F) To set screen to your desired "up" and "down" positions.

Adjust " + " : Screen drops more
Adjust " - " : Less drop

Important Note

- The upper limit and lower limit of the screen had been preset in factory. Any adjustment to these 2 limit switches may cause damages to the screen fabric. If adjusted, it will cause the following problems:
- a) The screen will roll into the frame and stop by force and not by the Upper Limit switch. This will cause overheating of motor which unable the screen to operate properly.
 - b) The depression of the bottom bar onto the fabric will cause horizontal mark on screen surface.
 - c) Adjusting the Lower Limit of the screen any lower than beyond the STOP sticker may cause the fabric to drop off

Disclaimer

Any adjustment to these 2 limit switches will void the warranty for the screen and Remaco will hold no responsibility for any damages to it. Please consult us if it is necessary to do any adjustment to the limit switch.